



Item No.	Description	HP1000NT - Part No.	HP1500NT - Part No.	HP2000NT - Part No.
1	OUTLET GRILLE	5332370	5332380	5332370
2	FRONT PANEL	6782470	6782480	6782490
3	WALL BRACKET	6532400	6532400	6532400
4	WATER COIL	7102500	7102530	7102550
5	FAN DECK ASSEMBLY	5252410	5252430	5252410
6	SCREW & WASHER	7362041 / 7392030	7362041 / 7392030	7362041 / 7392030
7	END CAP - LH	7661204	7661204	7661204
8	END CAP - RH	7661205	7661205	7661205
9	RJ SOCKET	5951010	5951010	5951010
10	BACK CASE	6022470	6022480	6022490
11	INFILL PIECE END BRACKET LH/RH	6341204 / 6341205	6341204 / 6341205	6341204 / 6341205
12	INLET PANEL RETAINER LH/RH	6341212 / 6341213	6341212 / 6341213	6341212 / 6341213
13	ECOPOWER BOARD	7263701	7263701	7263701
14	END PLATE	6862406	6862406	6862406
15	INLET GRILLE	5312470	5312470	5312470
16	ECOPOWER REMOTE CONTROL	7263630	7263630	7263630
17	FILTER	7402520	7402520	7402520