



Item No.	Description	T1000NT - Part No.	T1500NT - Part No.	T2000NT - Part No.
1	OUTLET GRILLE	5332270	5332280	5332270
2	FRONT PANEL	6791670	6791680	6791690
3	WALL BRACKET	6532200	6532200	6532200
4	ELEMENT	7292210 / 7292212	7292230	7292210 / 7292212
5	FAN DECK ASSEMBLY	5252320	5252340	5252320
6	PLENUM ASSEMBLY	5772310	5772330	5772310
7	SCREW & WASHER	7362041 / 7392030	7362041 / 7392030	7362041 / 7392030
8	END CAP - LH	7661202	7661202	7661202
9	END CAP - RH	7661203	7661203	7661203
10	THERMAL CUT OUT	7851110	7851110	7851110
11	RJ SOCKET	5951010	5951010	5951010
12	BACK CASE	6022370	6022380	6022390
13	INFILL PIECE END BRACKET LH/RH	6341202 / 6341203	6341202 / 6341203	6341202 / 6341203
14	INLET PANEL RETAINER LH/RH	6341212 / 6341213	6341212 / 6341213	6341212 / 6341213
15	ECOPOWER BOARD	7263701	7263701	7263701
16	END PLATE	6862405	6862405	6862405
17	INLET GRILLE	5312270	5312270	5312270
18	ECOPOWER REMOTE CONTROL	7263630	7263630	7263630
19	FILTER	7402510	7402510	7402510